

## Waterproofing and sealing against fuels and oils on concrete, masonry & blockwork surfaces

Products required

- MAXPLUG or MAXREST
- MAXSEAL FLEX
- MAXMESH
- MAXSEAL FOUNDATION
- SWEPCO PAVRON

1. Prepare area to be treated by removing any loose materials ensuring a clean and sound surface.

2. Any damage to the surface should be repaired using MAXPLUG or MAXREST.


3. Thoroughly wet the entire surface before applying the MAXSEAL FLEX coating by brush.

4. A coving should be placed in all corner joints using MAXREST.

5. MAXMESH, to be used on joints to provide added strength. Incorporate the MAXMESH into the first coat.

6. For economy on large areas use MAXSEAL FOUNDATION on rigid surfaces. 50mm overlap MAXSEAL FLEX

7. Apply a single coat of SWEPCO PAVRON three days after curing of the MAXSEAL products. Note – This information is based on information from the manufacturer and from our own experience. The information contained in this specification should be used in conjunction with the appropriate technical data bulletins and material safety data sheets available from our office or website.



### WATERPROOFING WITH OILS AND FUELS RESISTANCE DETAIL

**SwepDri**  
INTERNATIONAL

**SwepDri International**

ABN 60 003 944 803

ADDRESS  
PO BOX 694  
PADSTOW NSW 2211  
AUSTRALIA

TEL: + 61 2 9771 0011  
FAX: + 61 2 9771 0111  
WEB: www.swepdri.com.au  
EMAIL: info@swepdri.com.au

NATIONAL HOTLINE: 1300 303 301

NATIONAL FAXLINE: 1300 369 932